


Let's get your DIY done.  
This will be easy.

**FREEDOM**<sup>®</sup>  
OUTDOOR LIVING

## 5X6 NEW HAVEN STANDARD

- 1 in. x 1 in. rails
- $\frac{5}{8}$  in. pickets /  $3\frac{7}{8}$  in. picket spacing



Panel and Gates	Actual Size	Black Model #	SOS#
<b>A 5x6 New Haven Standard Panel</b>	<b>59in. H x 72-<math>\frac{5}{16}</math>in. W</b>	<b>73002246</b>	<b>384418</b>
B 5ft. x 4ft. New Haven Standard Straight Gate*	60- $\frac{1}{2}$ in. H x 46- $\frac{1}{2}$ in. W	73009477	384470
C 5ft. x 4ft. New Haven Standard Arched Gate*	60- $\frac{1}{2}$ in. H x 46- $\frac{1}{2}$ in. W	73009474	384469
I 5 ft. Adjustable Gate Kit		73050639	5020068


Posts	Black Model #	SOS#
D 2in. x 2in. x 88in. Line Post	73002265	384519
E 2in. x 2in. x 88in. Corner Post	73002266	384520
F 2in. x 2in. x 88in. End Post	73002267	384521
G 2in. x 2in. x 88in. Gate Post	73002268	384522
H 2in. x 2in. x 106in. Blank Post	73002392	384527

## How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels  
**Note:** panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
  - 1 post per panel + 1 end post to end the fence run
  - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

### Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run
- Gate posts – use on the hinge side to support the weight of the gate
- Fence panels
- ∖ Gate



Check with local building department for code requirements