


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING



6X6 PROVIDENCE STANDARD

- 1 in. x 1 in. rails
- 5/8 in. pickets / 3-7/8 in. picket spacing



Panel and Gates		Actual Size	Black Model #	SOS#
A	6x6 Providence Standard Panel	70-3/4in. H x 72-5/16in. W	73002352	384423
B	6ft. x 4ft. Providence Standard Straight Gate*	72-1/4in. H x 46-1/2in. W	73009377	384458
C	6ft. x 4ft. Providence Standard Arched Gate*	72-1/4in. H x 46-1/2in. W	73009374	384457


Posts		Black Model #	SOS#
D	2in. x 2in. x 106in. Line Post	73002410	384536
E	2in. x 2in. x 106in. Corner Post	73002404	384533
F	2in. x 2in. x 106in. End Post	73002406	384534
G	2in. x 2in. x 106in. Gate Post	73002408	384535
H	2in. x 2in. x 106in. Blank Post	73002392	384527

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run
- Gate posts – use on the hinge side to support the weight of the gate
- Fence panels
- ∖ Gate



Check with local building department for code requirements