



Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING



5X8 PROVIDENCE HEAVY DUTY

- 1-³/₁₆ in. x 1-¹/₂ in. rails
- ³/₄ in. pickets / 3-³/₄ in. picket spacing



Panel and Gates	Actual Size	Black Model #	SOS#
A 5x8 Providence Heavy Duty Panel	58-³/₁₆in. H x 94-1¹/₁₆in. W	73003515	384436
B 5ft. x 4ft. Providence Heavy Duty Straight Gate	60- ¹ / ₄ in. H x 46- ¹ / ₂ in. W	73010252	384494
C 5ft. x 4ft. Providence Heavy Duty Arched Gate	60- ¹ / ₄ in. H x 46- ¹ / ₂ in. W	73010249	384493


Posts	Black Model #	SOS#
D 2 ¹ / ₂ in. x 2 ¹ / ₂ in. x 88in. Line Post	73003517	384537
E 2 ¹ / ₂ in. x 2 ¹ / ₂ in. x 88in. Corner Post	73003524	384538
F 2 ¹ / ₂ in. x 2 ¹ / ₂ in. x 88in. End Post	73003525	384562
G 2 ¹ / ₂ in. x 2 ¹ / ₂ in. x 88in. Gate Post	73003958	384563
H 2 ¹ / ₂ in. x 2 ¹ / ₂ in. x 106in. Blank Post	73003644	391005

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run
- Gate posts – use on the hinge side to support the weight of the gate
- Fence panels
- ∖ Gate



Check with local building department for code requirements