Let's get your DIY done.
This will be easy.

FREEDOM® OUTDOOR LIVING

6X6 SHEFFIELD STANDARD

- 1 in. x 1 in. rails
- ⅝ in. pickets / 1-⅝ in. picket spacing



	Panel and Gates	Actual Size	Black Model #	SOS#
A	**6x6 Sheffield Standard Panel**	**71in. H x 72-5/16in. W**	**73008843**	**548074**
B	6ft. x 4ft. Sheffield Standard Straight Gate*	72-½in. H x 46-½in. W	73009513	548100
C	6ft. x 4ft. Sheffield Standard Arched Gate*	72-½in. H x 46-½in. W	73009510	548079

	Posts	Black Model #	SOS#
D	2in. x 2in. x 106in. Line Post	73002402	384532
E	2in. x 2in. x 106in. Corner Post	73002396	384529
F	2in. x 2in. x 106in. End Post	73002398	384530
G	2in. x 2in. x 106in. Gate Post	73002400	384531
H	2in. x 2in. x 106in. Blank Post	73002392	384527

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels

   Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
   - 1 post per panel + 1 end post to end the fence run
   - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run
- Gate posts – use on the hinge side to support the weight of the gate
- — Fence panels
- \ Gate



Check with local building department for code requirements

BY Barrette OUTDOOR LIVING