


Let's get your DIY done.  
This will be easy.


**FREEDOM**<sup>®</sup>  
OUTDOOR LIVING



## 4X8 PROVIDENCE HEAVY DUTY

- 1-<sup>3</sup>/<sub>16</sub> in. x 1-<sup>1</sup>/<sub>2</sub> in. rails
- <sup>3</sup>/<sub>4</sub> in. pickets / 3-<sup>3</sup>/<sub>4</sub> in. picket spacing

A



B



C



Panel and Gates		Actual Size	Black Model #	SOS#
<b>A</b>	<b>4x8 Providence Heavy Duty Panel</b>	<b>46-<sup>3</sup>/<sub>16</sub>in. H x 94-<sup>11</sup>/<sub>16</sub>in. W</b>	<b>73008961</b>	<b>384446</b>
B	4ft. x 4ft. Providence Heavy Duty Straight Gate*	48- <sup>1</sup> / <sub>4</sub> in. H x 46- <sup>1</sup> / <sub>2</sub> in. W	73010246	384492
C	4ft. x 4ft. Providence Heavy Duty Arched Gate*	48- <sup>1</sup> / <sub>4</sub> in. H x 46- <sup>1</sup> / <sub>2</sub> in. W	73010243	384489


Posts		Black Model #	SOS#
D	2 <sup>1</sup> / <sub>2</sub> in. x 2 <sup>1</sup> / <sub>2</sub> in. x 70in. Line Post	73009232	384725
E	2 <sup>1</sup> / <sub>2</sub> in. x 2 <sup>1</sup> / <sub>2</sub> in. x 70in. Corner Post	73009233	384727
F	2 <sup>1</sup> / <sub>2</sub> in. x 2 <sup>1</sup> / <sub>2</sub> in. x 70in. End Post	73009234	384728
G	2 <sup>1</sup> / <sub>2</sub> in. x 2 <sup>1</sup> / <sub>2</sub> in. x 70in. Gate Post	73009235	384746
H	2 <sup>1</sup> / <sub>2</sub> in. x 2 <sup>1</sup> / <sub>2</sub> in. x 106in. Blank Post	73003644	391005

## How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels  
**Note:** panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
  - 1 post per panel + 1 end post to end the fence run
  - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

### Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run
- Gate posts – use on the hinge side to support the weight of the gate
- Fence panels
- ∖ Gate



Check with local building department for code requirements