


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING

4X6 EASTON HEAVY DUTY

- 1-³/₁₆ in. x 1-¹/₂ in. rails
- ³/₄ in. pickets / 3-³/₄ in. picket spacing



Panel and Gates		Actual Size	Black Model #	SOS#	Pewter Model #	SOS#
A	4x6 Easton Heavy Duty Panel	48-¹/₂in. H x 72-⁵/₁₆in. W	73008974	384447	73009008	384450
B	4ft. x 4ft. Easton Heavy Duty Straight Gate*	50in. H x 46- ¹ / ₂ in. W	73010300	384495	73010407	384507
C	4ft. x 4ft. Easton Heavy Duty Arched Gate*	50in. H x 46- ¹ / ₂ in. W	73016236	384508	73016237	384509

Posts		Black Model #	SOS#	Pewter Model #	SOS#
D	2- ¹ / ₂ in. x 2- ¹ / ₂ in. x 70in. Line Post	73009236	384748	73009261	384773
E	2- ¹ / ₂ in. x 2- ¹ / ₂ in. x 70in. Corner Post	73009237	384750	73009262	384775
F	2- ¹ / ₂ in. x 2- ¹ / ₂ in. x 70in. End Post	73009238	384752	73009263	384776
G	2- ¹ / ₂ in. x 2- ¹ / ₂ in. x 70in. Gate Post	73009239	384754	73009264	112366
H	2- ¹ / ₂ in. x 2- ¹ / ₂ in. x 106in. Blank Post	73003644	391005	73003956	391009

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run
- Gate posts – use on the hinge side to support the weight of the gate
- Fence panels
- ∖ Gate

