


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING



4X8 KESWICK SCALLOP - SAND

- 1-½ in. pickets with 2-¼ in. spacing
- 2 in. x 3-½ in. top rail
- 2 in. x 6 in. bottom rail

A



B



C



Panel and Gates	Actual Size	Model#	SOS#
A 4x8 Keswick Scallop Picket Fence Kit - Sand (B)	48in. H x 94in. W	73011759	340382
B Keswick Scallop 4' Gate Kit - Sand (hinges included)†	49.5in. H x 46in. W	73014751	667006
C Keswick Scallop 5' Gate Kit - Sand (hinges included)†	49.5in. H x 58in. W	73014752	667007

Posts and Accessories	Model#	SOS#
D 5in. x 5in. x 84in. Line Post - Sand (B)	73011760	385294
E 5in. x 5in. x 84in. Corner Post - Sand (B)	73011761	385295
F 5in. x 5in. x 84in. End Post - Sand (B)	73011762	385296
G 5in. x 5in. x 82in. Post Insert*	73003718	430373
H 5in. x 5in. New England Post Top - Sand	73045004	1944650
I 4 oz. Tube Vinyl Adhesive	73047688	1966202

D



E



F



G



I



H




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements