

Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING


6X6 WELLINGTON - WHITE

- 6 in. boards
- 1-³/₄ in. x 2-³/₄ in. rails
- Classic lattice insert
- 14 day lead time



Panel	Actual Size	Model #	SOS#
A 6x6 Wellington Lattice Top - White	68in. H x 68in. W	73013822	183747

Posts and Accessories	Model #	SOS#
B 5in. x 5in. x 96in. Post - White	73013947	261012
C 5in. x 5in. Contemporary Post Top - White	73013956	428791
D 2pk. Set & Secure™ Bracket - White (screws included)	73004620	701345
E 4 oz. Tube Vinyl Adhesive	73047688	1966202
F Gate Framing Kit - White (hinges and latch included)	73013824	226837
G 5in. x 5in. x 94in. Post Insert*	73012353	430375




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements