
## Let's get your DIY done. This will be easy.



## 3X8 NEWPORT - WHITE


- 1-% in. pickets with 3-13/16 in. spacing
- 1-3/4 in. x 2-3/4 in. rails
- 14 day lead time



Panel	Actual Size	Model #	SOS#
A 3x8 Newport Picket - White	34in. H x 91.75in. W	73013948	275472

	Posts and Accessories	Model #	SOS#
В	4in. x 4in. x 72in. Post - White	73002277	385239
С	4in. x 4in. Gothic Post Top - White	73013954	425788
D	2pk. Set & Secure™ Bracket - White (screws included)	73004620	701345
Е	4 oz. Tube Vinyl Adhesive	73047688	1966202
F	Gate Framing Kit - White (hinges and latch included)	73013824	226837
G	4in. x 4in. x 58in. Post Insert*	73014646	472330

<sup>\*</sup>Required support for gate posts and strength for hardware connections.



## How to calculate fence materials:


- Determine total number of lineal feet and subtract footage for gates
- 2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels

Note: panels can be cut to shorter width if necessary

- 3. Calculate # of posts needed:
  - 1 post per panel + 1 end post to end the fence run
  - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

## Key:

- Line posts use when connecting fence panels in a straight line
- Corner posts use when connecting fence panels at a 90 degree angle
- End posts use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements

