


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING




6X6 FREEPORT - SAND

- 6 in. tongue & groove boards
- 1-³/₄ in. x 2-³/₄ in. top rail
- 1-³/₄ in. x 5-¹/₂ in. middle & bottom rails



Panel and Gates	Actual Size	Model#	SOS#
A 6x6 Freeport Lattice Top Fence Kit - Sand (AE)	70in. H x 70in. W	73014381	546574
B Freeport 4' Gate Kit - Sand (hinges included)†	71.5in. H x 46in. W	73024928	819042
C Freeport 5' Gate Kit - Sand (hinges included)†	71.5in. H x 58in. W	73024939	819043

Posts and Accessories	Model#	SOS#
D 5in. x 5in. x 102in. Line Post - Sand (AE)	73014382	546575
E 5in. x 5in. x 102in. Corner Post - Sand (AE)	73014383	546576
F 5in. x 5in. x 102in. End Post - Sand (AE)	73014384	546577
G 5in. x 5in. x 94in. Post Insert*	73012353	430375
H 5in. x 5in. New England Post Top - Sand	73045004	1944650
I 4 oz. Tube Vinyl Adhesive	73047688	1966202




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements