Let's get your DIY done. This will be easy.



A

4X6 CARLISLE	SCALLOP -	WHITE
--------------	-----------	-------

- $1-\frac{1}{2}$ in. pickets with $2-\frac{5}{16}$ in. spacing
- 2 in. x 3-1/2 in. top & bottom rails
- 14 day lead time

lltu	utt	Ц.
		Π



В



С

	Panel and Gates	Actual Size	Model #	SOS#
Α	4x6 Carlisle Scallop Picket Fence Kit - White (AB)	46in. H x 70in. W	73014407	546652
В	Carlisle Scallop 4' Gate Kit - White (hinges included)†	48in. H x 46in. W	73025383	818958
С	Carlisle Scallop 5' Gate Kit - White (hinges included)†	48in. H x 58in. W	73025384	818959
			F	

	Posts and Accessories	Model #	SOS#	U	E	Г	G
D	4in. x 4in. x 72in. Line Post - White (AB)	73014409	546641				
Е	4in. x 4in. x 72in. Corner Post - White (AB)	73014410	546642				
F	4in. x 4in. x 72in. End Post - White (AB)	73014411	546643				1.023
G	4in. x 4in. x 58in. Post Insert*	73014646	472330				
Н	4in. x 4in. Pyramid Post Top - White	73013953	425710				Н
I	4 oz. Tube Vinyl Adhesive	73047688	1966202				

*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:


- 1. Determine total number of lineal feet and subtract footage for gates
- 2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels

Note: panels can be cut to shorter width if necessary

- 3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts use when connecting fence panels in a straight line
- Corner posts use when connecting fence panels at a 90 degree angle
- End posts use when ending a fence run or on either side of a gate



Check with local building department for code requirements



Fence panels