

Let's get your DIY done.  
This will be easy.

**FREEDOM**<sup>®</sup>  
OUTDOOR LIVING

## 4X6 DURHAM - WHITE

- 3 in. pickets with 2-<sup>7</sup>/<sub>8</sub> in. spacing
- 2 in. x 3-<sup>1</sup>/<sub>2</sub> in. top & bottom rails
- 14 day lead time

A



B



C



Panel and Gates	Actual Size	Model #	SOS#
<b>A 4x6 Durham Picket Fence Kit - White (AC)</b>	<b>46in. H x 70in. W</b>	<b>73014450</b>	<b>546688</b>
B Durham 4' Gate Kit - White (hinges included)†	48in. H x 46in. W	73025401	818968
C Durham 5' Gate Kit - White (hinges included)†	48in. H x 58in. W	73025402	818969

Posts and Accessories	Model #	SOS#
D 4in. x 4in. x 72in. Line Post - White (AC)	73014451	546689
E 4in. x 4in. x 72in. Corner Post - White (AC)	73014452	546690
F 4in. x 4in. x 72in. End Post - White (AC)	73014453	546691
G 4in. x 4in. x 58in. Post Insert*	73014646	472330
H 4in. x 4in. Pyramid Post Top - White	73013953	425710
I 4 oz. Tube Vinyl Adhesive	73047688	1966202

D



E



F



G



I



H




\*Required support for gate posts and strength for hardware connections.

## How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels  
**Note:** panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
  - 1 post per panel + 1 end post to end the fence run
  - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

### Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements