
## Let's get your DIY done. This will be easy.



## **6X8 BOLTON - WHITE**


- 6 in. tongue & groove boards
- 1-3/4 in. x 5-1/2 in. top & bottom rails
- Aluminum reinforced bottom rail



Panel and Gates		Actual Size	Model #	SOS#
<b>A</b>	6x8 Bolton Privacy Fence Kit - White (DE)	70in. H x 94in. W	73014727	666950
	Bolton 4' Gate Kit - White (hinges included)†	71.5in. H x 46in. W	73025125	819044
С	Bolton 5' Gate Kit - White (hinges included)†	71.5in. H x 58in. W	73025126	819045

		Posts and Accessories	Model #	SOS#
	D	5in. x 5in. x 108in. Line Post - White (DE)	73024020	666951
	Ε	5in. x 5in. x 108in. Corner Post - White (DE)	73024022	666952
	F	5in. x 5in. x 108in. End Post - White (DE)	73024021	666953
	G	5in. x 5in. x 106in. Gate Post Insert*	73041348	1143443
	Н	5in. x 5in. New England Top - White	73045003	1870861
	I	4 oz. Tube Vinyl Adhesive	73047688	1966202





## How to calculate fence materials:


- 1. Determine total number of lineal feet and subtract footage for gates
- 2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels

Note: panels can be cut to shorter width if necessary

- 3. Calculate # of posts needed:
  - 1 post per panel + 1 end post to end the fence run
  - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

## Key:

- Line posts use when connecting fence panels in a straight line
- Corner posts use when connecting fence panels at a 90 degree angle
- End posts use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements

