


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING


6X8 CONWAY - WHITE

- 6 in. tongue & groove boards
- 2 in. x 3-½ in. top rail
- 1-¾ in. x 5-½ in. middle & aluminum reinforced bottom rail



Panel and Gates	Actual Size	Model #	SOS#
A 6x8 Conway Lattice Top Fence Kit - White (EF)	70in. H x 94in. W	73025137	819028
B Conway 4' Gate Kit - White (hinges included)†	71.5in. H x 46in. W	73025141	819029
C Conway 5' Gate Kit - White (hinges included)†	71.5in. H x 58in. W	73025142	819030

Posts and Accessories	Model #	SOS#
D 5in. x 5in. x 108in. Line Post - White (EF)	73025138	819034
E 5in. x 5in. x 108in. Corner Post - White (EF)	73025139	819035
F 5in. x 5in. x 108in. End Post - White (EF)	73025140	819036
G 5in. x 5in. x 106in. Gate Post Insert*	73041348	1143443
H 5in. x 5in. New England Top - White	73045003	1870861
I 4 oz. Tube Vinyl Adhesive	73047688	1966202




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements