


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING




6X8 BARINGTON BOARDWALK - CYPRESS

- 6 in. tongue & groove boards
- 1-³/₄ in. x 7 in. top & bottom rails



Product Description	Actual Size	Model #	SOS#
A 6x8 Barington Boardwalk Horizontal Fence Panel Kit - Cypress (Al)	70.5in. H x 94in. W	73045762	4968172
B Barington Horizontal 4' Gate Kit - Cypress (hinges included)†	70.5in. H x 46in. W	73045767	4968177
C Barington Horizontal 5' Gate Kit - Cypress (hinges included)†	70.5in. H x 58in. W	73045827	4968178

Posts and Accessories	Model #	SOS#
D 5in. x 5in. x 108in. Line Post - Cypress (Al)	73045763	4968174
E 5in. x 5in. x 108in. Corner Post - Cypress (Al)	73045764	4968175
F 5in. x 5in. x 108in. End Post - Cypress (Al)	73045765	4968176
G 5in. x 5in. x 106in. Gate Post Insert*	73041348	1143443
H 5in. x 5in. Pyramid Post Top - Cypress	73013829	1097951
I 4 oz. Tube Vinyl Adhesive	73047688	1966202




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements