


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING


BOLTON TRANSITION PANELS - WHITE

- 6 in. tongue & groove boards
- 1-³/₄ in. x 5-¹/₂ in. top & bottom rails
- Aluminum reinforced bottom rail



Panel and Gates	Actual Size	Model #	SOS#
A 6'-5' Bolton Privacy Transition Fence Kit - White (DE-ZA)	94in. W x 70in. H to 58in. H	73048526	2468017
B 6'-4' Bolton Privacy Transition Fence Kit - White (DE-ZB)	91.5in. W x 70.25in. H to 45.5in. H	73048528	2468019

Posts and Accessories	Model #	SOS#
C 5in. x 5in. x 108in. Line Post - White (DE)	73024020	666951
D 5in. x 5in. x 108in. Corner Post - White (DE)	73024022	666952
E 5in. x 5in. x 108in. End Post - White (DE)	73024021	666953
C 5in. x 5in. x 96in. Line Post - White (ZA)	73014890	666957
D 5in. x 5in. x 96in. Corner Post - White (ZA)	73014892	666959
E 5in. x 5in. x 96in. End Post - White (ZA)	73014891	666958
C 5in. x 5in. x 84in. Line Post - White (ZB)	73014884	666963
D 5in. x 5in. x 84in. Corner Post - White (ZB)	73014886	666965
E 5in. x 5in. x 84in. End Post - White (ZB)	73014885	666964




How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements