


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING


6X8 WAVERLY - WHITE

- 6 in. boards with 1" spacing
- 2 in. x 3-½ in. top rail
- 2 in. x 6 in. Aluminum reinforced bottom rails
- 14 day lead time



	Product Description	Actual Size	Model #	SOS#
A	6x8 Waverly Semi-Privacy Fence Kit - White (K)	72in. H x 94in. W	73048536	3159359
B	Waverly Semi-Privacy 4' Gate Kit - White (hinges included)†	73.5in. H x 46in. W	73048573	3159360
C	Waverly Semi-Privacy 5' Gate Kit - White (hinges included)†	73.5in. H x 58in. W	73048574	3159361

	Posts and Accessories	Model #	SOS#
D	5in. x 5in. x 108in. Line Post - White (K)	73011310	818945
E	5in. x 5in. x 108in. Corner Post - White (K)	73011311	818946
F	5in. x 5in. x 108in. End Post - White (K)	73011312	818947
G	5in. x 5in. x 106in. Gate Post Insert*	73041348	1143443
H	5in. x 5in. New England Top - White	73045003	1870861
I	4 oz. Tube Vinyl Adhesive	73047688	1966202




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements