


Let's get your DIY done.
This will be easy.

FREEDOM[®]
OUTDOOR LIVING


6X6 LOUVERED FENCE - SAND

- 6in. Louvered boards
- Design allows for air circulation through boards, perfect for warm weather locations



Panel and Gates	Actual Size	Model #	SOS#
A 6x6 Louvered Privacy Fence Kit - Sand (ZE)	70in. H x 70in. W	73050574	5076410
B Louvered 4' Gate Kit - Sand (hinges included)†	5.5in. H x 46in. W	73050567	5076407
C Louvered 5' Gate Kit - Sand (hinges included)†	5.5in. H x 58in. W	73050571	5076406

Posts and Accessories	Model #	SOS#
D 5in. x 5in. x 102in. Line Post - Sand (ZE)	73050555	5076400
E 5in. x 5in. x 102in. Corner Post - Sand (ZE)	73050557	5076402
F 5in. x 5in. x 102in. End Post - Sand (ZE)	73050559	5076404
G 5in. x 5in. x 100in. Gate Post Insert*	73040719	5106442
H 5in. x 5in. Pyramid Post Top - Sand	73003769	385325
I 4 oz. Tube Vinyl Adhesive	73047688	1966202




*Required support for gate posts and strength for hardware connections.

How to calculate fence materials:

1. Determine total number of lineal feet and subtract footage for gates
2. Calculate # of fence panels needed: Total lineal feet divided by panel width (feet) = total # of panels
Note: panels can be cut to shorter width if necessary
3. Calculate # of posts needed:
 - 1 post per panel + 1 end post to end the fence run
 - 1 end/gate post per gate (don't forget 2 post inserts for each gate)

Key:

- Line posts – use when connecting fence panels in a straight line
- Corner posts – use when connecting fence panels at a 90 degree angle
- End posts – use when ending a fence run or on either side of a gate
- Fence panels



Check with local building department for code requirements